

WIZ127SR User's Manual

(Version 1.0)



©2013 WIZnet Co., Ltd. All Rights Reserved.

☞ For more information, visit our website at <http://www.wiznet.co.kr>

Document Revision History

Date	Revision	Changes
2013-04-01	V1.00	Official Release

Information in this document is believed to be accurate and reliable. However, WIZnet does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

WIZnet reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

COPYRIGHT NOTICE

Copyright 2013 WIZnet Co., Ltd. All Rights Reserved.

Contact Information

- WIZnet US : sales_team@wiznettechnology.com / support_team@wiznettechnology.com
- WIZnet HK : sales@wiznet.hk
- WIZnet EU : sales@wiznet.eu
- WIZnet HQ : sales@wiznet.co.kr / support@wiznet.co.kr

For more information, visit our website at <http://www.wiznet.co.kr>

Table of Contents

1. INTRODUCTION	1
1.1. KEY FEATURE	1
2. HARDWARE SPECIFICATIONS	2
2.1. PIN ASSIGNMENT AND DESCRIPTION	2
2.2. DIMENSION	3
2.3. ELECTRICAL CHARACTERISTICS	4
2.3.1. Absolute Maximum Rating.....	4
2.3.2. DC Characteristics.....	4
2.3.3. POWER DISSIPATION.....	4
2.4. APPLICATION SCHEMATICS.....	5
2.4.1. WIZ127SR-BASE.....	5
2.4.2. RS485/422.....	6
3. PROGRAMMERS' GUIDE	7
3.1. SERIAL COMMANDS.....	7
3.1.1. Serial Command Format.....	7
3.1.2. Reply Code.....	7
3.1.3. Command Code.....	7
3.2. DATA MODE AND COMMAND MODE	15
3.2.1. Data mode.....	15
3.2.2. Serial Command mode.....	16
3.2.3. How to switch the mode.....	16
FRAME FORMAT.....	16
HARDWARE CONFIGURATION EXAMPLES	19
Read Parameter.....	19
Changing IP Address.....	19
3.3. HOW TO GET THE SOCKET STATUS	19
3.4. HOW TO HANDLE EXTRA GPIO PINS.....	19
4. HOW TO CONFIGURE WITH WIZ127SR	20
4.1. CONFIGURING WITH UDP BROADCASTING AND WIZ127SR CONFIGURATION TOOL.....	20
4.1.1. Network Configurations.....	20
4.1.2. Serial Configuration.....	23
4.1.3. Option Configuration.....	27
4.2. CONFIGURING WITH WEB BROWSER.....	28
4.3. CONFIGURING WITH TELNET	29
5. HOW TO UPLOAD A NEW FIRMWARE	31
6. QUICK INSTALLATION AND TEST	34
7. WARRANTY	38

Figures

FIGURE 1 PIN ASSIGNMENT	2
FIGURE 2 DIMENSION.....	3
FIGURE 3 WIZ127SR BASE BOARD SCHEMATIC	5
FIGURE 4 REFERENCE SCHEMATIC FOR INTERFACING TO RS485/422	6
FIGURE 5. CONFIGURATION TOOL (NETWORK CONFIGURATION)	20
FIGURE 6. CONFIGURATION TOOL (SERIAL CONFIGURATION)	23
FIGURE 7. CONFIGURATION TOOL (OPTION CONFIGURATION)	27
FIGURE 8. CONFIGURATION TOOL	31
FIGURE 9. OPEN DIALOG BOX FOR UPLOADING	32
FIGURE 10. FIRMWARE UPLOADING WINDOW	33
FIGURE 11. COMPLETE UPLOADING	33

Tables

TABLE 1 PIN DESCRIPTION.....	2
TABLE 2 ABSOLUTE MAXIMUM RATING	4
TABLE 3 DC CHARACTERISTIC	4
TABLE 4 POWER DISSIPATION	4
TABLE 5. SERIAL CONFIGURATION FRAME FORMAT	7
TABLE 6. SERIAL CONFIGURATION REPLY FRAME FORMAT	7
TABLE 7. SERIAL CONFIGURATION STX & ETX	7
TABLE 8. SERIAL CONFIGURATION REPLY CODE.....	7
TABLE 10. HARDWARE CONFIGURATION FRAME FORMAT	16
TABLE 11. HARDWARE CONFIGURATION REPLY FRAME FORMAT.....	17
TABLE 12. HARDWARE CONFIGURATION COMMAND CODE.....	17
TABLE 14. HARDWARE CONFIGURATION ENTRANCE MESSAGE	17
TABLE 13. HARDWARE CONFIGURATION PARAMETER DESCRIPTIONS	18

1. Introduction

WIZ127SR is a 2 ports gateway module that converts RS-232 protocol into TCP/IP protocol. This module enables remote gauging, remote management of the device through the network based on the Ethernet and the TCP/IP by connecting to existing equipment with RS-232 serial interface. In other words, WIZ127SR is a protocol converter that transmits the data sent by serial equipment as TCP/IP data type or vice versa.

1.1. Key Feature

- Plug & Play Type Serial to Ethernet Gateway module
 - Adds Network Function Simply and Quickly
 - Provides Firmware Customization
- Hardware compatible with WIZ100SR
- 2port serial to Ethernet
 - supports RS-232
 - supports RS-422/485 by adding RS-232 to RS-422/485 converter
- Supports TCP & UDP communication
- Supports DHCP, DNS, NTP
- Easy configuration
 - Web, Telnet, Configuration Tool & Serial Command
- GPIO Extendable (Max. 10GPIOs), by firmware customization
- 10/100 Ethernet & Max.921,600bps Serial Interface
- Supports Static IP, DHCP, PPPoE
- Supports DNS function
- RoHS compliant

2. Hardware Specifications

2.1. Pin Assignment and Description




Figure 1 Pin Assignment

Pin name	Description	I/O	Attribute
RESET	Reset (Active High)	Input	-
UART1_TX	TX Data Output for UART1	Output	CMOS/TTL/5V tolerant Input
UART1_RX	RX Data Input for UART1	Input	CMOS/TTL/5V tolerant Input
UART1_CTS	Clear To Send for UART1	Input	CMOS/TTL/5V tolerant Input
UART1_RTS	Request To Send for UART1	Output	CMOS/TTL/5V tolerant Input
UART2_CTS	Clear To Send for UART2	Input	CMOS/TTL/5V tolerant Input
UART2_RTS	Request To Send for UART2	Output	CMOS/TTL/5V tolerant Input
UART2_TX	TX Data Output for UART2	Output	CMOS/TTL/5V tolerant Input
UART2_RX	RX Data Input for UART2	Input	CMOS/TTL/5V tolerant Input
(*)STATUS1	High: Not connected Low: Connected	Input/Output	CMOS/TTL/5V tolerant Input This pin is activated if it is asserted low during MCU booting.
STATUS2	High: Not connected Low: Connected	Output	CMOS/TTL/5V tolerant Input
RXIN	Ethernet Differential Input-	Input	-
RXIP	Ethernet Differential Input+	Input	-
TXON	Ethernet Differential Output-	Output	-
TXOP	Ethernet Differential Output+	Output	-
LINKLED_M0	Ethernet Link LED	Output	-
SPDLED_M1	Ethernet Speed LED	Output	-
FDXLED_M2	Ethernet Full-duplex LED	Output	-
VDD3V3	3.3V Power Supply	Input	-
VDD3V3A	Analog 3.3V Output	Output	-
PB11	Factory Reset (Active Low)	Input	CMOS/TTL/5V tolerant Input This pin is activated if it is asserted low during MCU booting.
PB12, PB13	GPIO Output	Output	CMOS/TTL/5V tolerant Input
PB14, PB15	GPIO Input	Input	CMOS/TTL/5V tolerant Input
PB0, PB1, PB5	Reserved GPIO	Input/Output	CMOS/TTL/5V tolerant Input
PC14, PC15	Reserved GPIO	Input/Output	CMOS/TTL/5V tolerant Input

(*) This pin can be used for H/W Trigger (Active Low).

Table 1 Pin Description

2.2. Dimension




Figure 2 Dimension

2.3. Electrical Characteristics

2.3.1. Absolute Maximum Rating

Symbol	Parameter	Rating	Unit
VDD	DC Supply voltage	-0.5 to 3.63	V
VIN	DC Input voltage	-0.5 to 3.63	V
IIN	DC Input current	5	mA
TOP	Operating temperature	0 to 70	°C
TSTG	Storage temperature	TBD	°C

Table 2 Absolute Maximum Rating

2.3.2. DC Characteristics

Symbol	Parameter	Test Conditon	Min	Typ	Max	Unit
VDD	DC Supply voltage	Junction temperature is from -55°C to 125°C	2.97		3.6	V
VIH	High level input voltage		2.0		3.6	V
VIL	Low level input voltage		0.3		0.8	V
VOH	High level output voltage		2.4			V
VOL	Low level output voltage				0.4	V
Ii	Input Current	VIN = VDD			5	μA

Table 3 DC Characteristic

2.3.3. POWER DISSIPATION

Test Condition(VCC3.3V, Temperature 25°C)

Condition	Min	Typ	Max	Unit
100M Link	-	200	215	mA
10M Link	-	147	162	mA
Loss Link	-	158	173	mA
100M Transmitting	-	200	215	mA
10M Transmitting	-	147	162	mA

Table 4 Power Dissipation

2.4. Application Schematics

2.4.1. WIZ127SR-BASE




Figure 3 WIZ127SR Base board schematic

2.4.2. RS485/422





Figure 4 Reference schematic for interfacing to RS485/422

3. Programmers' Guide

3.1. Serial Commands

3.1.1. Serial Command Format

It is possible to configure WIZ127SR by using serial command. By inputting specified 3 characters you can enter into the configuration mode. The characters can be defined at the Configuration Tool.

< Frame Format >

Command Frame format

Descriptor	STX	Command code	Parameter	ETX
Length(bytes)	1	2	Variable	1

Table 5. Serial Configuration Frame format

Reply Frame format

Descriptor	STX	Reply code	Parameter	ETX
Length(bytes)	1	1	Variable	1

Table 6. Serial Configuration Reply Frame format

STX & ETX

Setting	Comments
STX	'<': Hex = 3Ch
ETX	'>': Hex = 3Eh

Table 7. Serial Configuration STX & ETX

3.1.2. Reply Code

Reply	Comments
S	Command was successful
F	Command failed
0	Invalid STX
1	Invalid command
2	Invalid parameter
3	Invalid ETX
E	Enter Serial Command Mode

Table 8. Serial Configuration Reply Code

3.1.3. Command Code

Command	Category	Description
WI	Format	<WIxxx.xxx.xxx.xxx>
	Meaning	Set Local IP ex) <WI192.168.11.133>
	Response	<S>
RI	Format	<RI>

	Meaning	Get the current WIZ127SR's Local IP address Its response format is like below. <S[IP Addr]> [IP Addr] : Server's IP address in a dotted decimal format ex) <RI>				
	Response	<S192.168.0.100>				
WS	Format	<WSxxx.xxx.xxx.xxx>				
	Meaning	Set Subnet Mark ex) <WS255.255.255.0>				
	Response	<S>				
RS	Format	<RS>				
	Meaning	Get the current WIZ127SR's Subnet Mask Its response format is like below. <S[Subnet]> [Subnet] : Server's IP address in a dotted decimal format ex) <RS>				
	Response	<S255.255.255.0>				
WG	Format	<WGxxx.xxx.xxx.xxx>				
	Meaning	Set Gateway Address ex) <WG192.168.11.1>				
	Response	<S>				
RG	Format	<RG>				
	Meaning	Get the current WIZ127SR's Gateway address Its response format is like below. <S[IP Addr]> [IP Addr] : Server's IP address in a dotted decimal format ex) <RG>				
	Response	<S192.168.0.1>				
WP	Format	<WPxxxx>				
	Meaning	Set Local port number ex) <WP35000>				
	Response	<S>				
RP	Format	<RP>				
	Meaning	Get the current WIZ127SR's Local port number Its response format is like below. <S[Port]> [Port] : Server's IP address in a dotted decimal format ex) <RP>				
	Response					
WD	Format	<WDx>				
	Meaning	Set the method of setting WIZ127SR's IP address <table border="1" data-bbox="584 1989 1369 2020"> <thead> <tr> <th style="background-color: yellow;">Parameter's Value</th> <th style="background-color: yellow;">Meaning</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> </tbody> </table>		Parameter's Value	Meaning	
Parameter's Value	Meaning					

		<table border="1"> <tr> <td>0</td> <td>Static mode</td> </tr> <tr> <td>1</td> <td>DHCP mode</td> </tr> <tr> <td>2</td> <td>PPPoE mode</td> </tr> </table>	0	Static mode	1	DHCP mode	2	PPPoE mode						
0	Static mode													
1	DHCP mode													
2	PPPoE mode													
	Response	<S>												
RD	Format	<RD>												
	Meaning	<p>Get the current WIZ127SR's method setting its IP address Its response format is like below. <S[Mode]></p> <p>[Mode] : Server's IP address in a dotted decimal format</p> <p>ex) <RD></p>												
	Response													
WM	Format	<WMx>												
	Meaning	<p>Set the operation mode of a TCP socket</p> <table border="1"> <thead> <tr> <th>Parameter's Value</th> <th>Meaning</th> <th>Remarks</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>TCP Client</td> <td>The TCP socket try to connect to the peer until the connection is established</td> </tr> <tr> <td>1</td> <td>TCP Mixed</td> <td>This mode is the same to TCP Server mode at first, but While any connection is not established, if WIZ127SR get any data via UART then WIZ127SR make TCP socket be a TCP Client socket and try to connect to the specified peer system.</td> </tr> <tr> <td>2</td> <td>TCP Server</td> <td>The TCP socket is in Listen mode waiting for a request of connection from any peer system.</td> </tr> </tbody> </table> <p>ex) <WM0></p>	Parameter's Value	Meaning	Remarks	0	TCP Client	The TCP socket try to connect to the peer until the connection is established	1	TCP Mixed	This mode is the same to TCP Server mode at first, but While any connection is not established, if WIZ127SR get any data via UART then WIZ127SR make TCP socket be a TCP Client socket and try to connect to the specified peer system.	2	TCP Server	The TCP socket is in Listen mode waiting for a request of connection from any peer system.
	Parameter's Value	Meaning	Remarks											
0	TCP Client	The TCP socket try to connect to the peer until the connection is established												
1	TCP Mixed	This mode is the same to TCP Server mode at first, but While any connection is not established, if WIZ127SR get any data via UART then WIZ127SR make TCP socket be a TCP Client socket and try to connect to the specified peer system.												
2	TCP Server	The TCP socket is in Listen mode waiting for a request of connection from any peer system.												
Response	<S>													
RM	Format	<RM>												
	Meaning	<p>Get the current data communication socket's operation mode Its response format is like below. <S[Mode]></p> <p>[Mode] : Server's IP address in a dotted decimal format</p> <p>ex) <RM></p>												
	Response													
WK	Format	<WKx>												
	Meaning	<p>Set the protocol of the communication socket with one of two mode.</p> <table border="1"> <thead> <tr> <th>Parameter's Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>TCP</td> </tr> <tr> <td>1</td> <td>UDP</td> </tr> </tbody> </table> <p>ex) <WK0></p>	Parameter's Value	Meaning	0	TCP	1	UDP						
	Parameter's Value	Meaning												
0	TCP													
1	UDP													
Response	<S>													
RK	Format	<RK>												

	Meaning	<p>Get the current data communication socket's protocol type. Its response format is like below. <S[Protocol]></p> <p>[Protocol] : Server's IP address in a dotted decimal format</p> <p>ex) <RK></p>																																																		
	Response																																																			
WB	Format	<WB[b][d][p][f]>																																																		
	Meaning	<p>Configure UART with four parameters [b], [d], [p] and [f] are a byte parameters, and those have the meaning as below</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td rowspan="8">[b] : baud rate</td> <td>c</td> <td>921600 bps</td> </tr> <tr> <td>b</td> <td>460800 bps</td> </tr> <tr> <td>a</td> <td>230400 bps</td> </tr> <tr> <td>1</td> <td>115200 bps</td> </tr> <tr> <td>2</td> <td>57600 bps</td> </tr> <tr> <td>3</td> <td>38400 bps</td> </tr> <tr> <td>4</td> <td>19200 bps</td> </tr> <tr> <td>5</td> <td>9600 bps</td> </tr> <tr> <td rowspan="3">[d] : data bits size</td> <td>6</td> <td>4800 bps</td> </tr> <tr> <td>7</td> <td>2400 bps</td> </tr> <tr> <td>8</td> <td>1200 bps</td> </tr> <tr> <td rowspan="3">[p] : parity</td> <td>7</td> <td>7 bits</td> </tr> <tr> <td>8</td> <td>8 bits</td> </tr> <tr> <td>9</td> <td>9 bits</td> </tr> <tr> <td rowspan="4">[f] : flow control</td> <td>0</td> <td>No Parity</td> </tr> <tr> <td>1</td> <td>Odd Parity</td> </tr> <tr> <td>2</td> <td>Even Parity</td> </tr> <tr> <td>3</td> <td>None</td> </tr> <tr> <td rowspan="3"></td> <td>2</td> <td>RTS/CTS</td> </tr> <tr> <td>3</td> <td>DSR/DTR</td> </tr> <tr> <td>4</td> <td>RTS Only(For RS485)</td> </tr> </tbody> </table> <p>ex) <WB1800> => 115200, 8 bits, no parity, no flow control</p>	Parameter	Value	Meaning	[b] : baud rate	c	921600 bps	b	460800 bps	a	230400 bps	1	115200 bps	2	57600 bps	3	38400 bps	4	19200 bps	5	9600 bps	[d] : data bits size	6	4800 bps	7	2400 bps	8	1200 bps	[p] : parity	7	7 bits	8	8 bits	9	9 bits	[f] : flow control	0	No Parity	1	Odd Parity	2	Even Parity	3	None		2	RTS/CTS	3	DSR/DTR	4	RTS Only(For RS485)
	Parameter	Value	Meaning																																																	
	[b] : baud rate	c	921600 bps																																																	
b		460800 bps																																																		
a		230400 bps																																																		
1		115200 bps																																																		
2		57600 bps																																																		
3		38400 bps																																																		
4		19200 bps																																																		
5		9600 bps																																																		
[d] : data bits size	6	4800 bps																																																		
	7	2400 bps																																																		
	8	1200 bps																																																		
[p] : parity	7	7 bits																																																		
	8	8 bits																																																		
	9	9 bits																																																		
[f] : flow control	0	No Parity																																																		
	1	Odd Parity																																																		
	2	Even Parity																																																		
	3	None																																																		
	2	RTS/CTS																																																		
	3	DSR/DTR																																																		
	4	RTS Only(For RS485)																																																		
Response	<S>																																																			
RB	Format	<RB>																																																		
	Meaning	<p>Get the current configuration information of WIZ127SR's serial interface. Its response format is like below. <S[baud rate][data size][parity][flow control]></p> <p>ex) <RB></p>																																																		
	Response	<S1800>																																																		
WT	Format	<WT[y]>																																																		
	Meaning	<p>Set whether serial command will be allowed, or not</p> <p>[y] = 0 : Disable [y] = 1 : Enable</p> <p>ex) <WT1></p>																																																		
	Response	<S>																																																		
RT	Format	<RT>																																																		

	Meaning	<p>Get the current setting of serial command method Its response format is like below. <S[Option]></p> <p>[Option] : Server's IP address in a dotted decimal format</p> <p>ex) <RT></p>
	Response	<S1>
WU	Format	<WU[y]>
	Meaning	<p>Set Whether DNS service will be allowed</p> <p>[y] = 0 : Not use [y] = 1 : Use</p> <p>ex) <WU1></p>
	Response	<S>
RU	Format	<RU>
	Meaning	<p>Get whether DNS mode is enabled or not Its response format is like below. <S[flag]></p> <p>[flag] : 0 = Not Use, 1 = Use</p> <p>ex) <RU></p>
	Response	<S 1>
WE	Format	<WE[ch][ch][ch]>
	Meaning	<p>Set character string using for Software trigger in order to enter serial command mode. [ch] is a ASCII character represented in its hexadecimal format. For example, if user wants use 'A' as [ch] then user should input its ASCII code in hexadecimal format, '4' and '1', not 'A'.</p> <p>ex)If character string for software trigger is "+++" then <WE2B2B2B></p>
	Response	<S>
RE	Format	<RE>
	Meaning	<p>Get the current character string for software trigger to enter the serial command mode. Its response format is like below. <S[ch1][ch2][ch3]></p> <p>[IP Addr] : Server's IP address in a dotted decimal format</p> <p>ex) <RE></p>
	Response	<S2B2B2B>
WX	Format	<WX[IP Addr]>
	Meaning	<p>Set Server's IP address to connect when the data socket is defined as Client mode or Mixed mode. If user defined the data socket as a Server mode, WIZ127SR don't care this Server's IP address.</p> <p>[IP Addr] : Server's IP address in a dotted decimal format</p> <p>ex) <WX192.168.11.144></p>
	Response	<S>
RX	Format	<RX>

	Meaning	<p>Get the current Server's IP address Its response format is like below. <S[IP Addr]></p> <p>[IP Addr] : Server's IP address in a dotted decimal format</p> <p>ex) <RX></p>
	Response	<S192.168.0.115>
WN	Format	<WN[port]>
	Meaning	<p>Set Server's port number to connect when the data socket is defined as Client mode or Mixed mode.</p> <p>[port] : Server's port number in a decimal format. Its range is 0 to 65535</p> <p>ex) <WN5000></p>
	Response	<S>
RN	Format	<RN>
	Meaning	<p>Get the current Server's Port number Its response format is like below. <S[Port number]></p> <p>[IP Addr] : Server's IP address in a dotted decimal format</p> <p>ex) <RN></p>
	Response	<S5000>
WR	Format	<WR>
	Meaning	<p>Restart WIZ127SR Some commands need reboot of WIZ127SR in order that those command affect to WIZ127SR's configuration to operate properly. So, we recommend you do use this command after all command you issued, to guarantee WIZ127SR operate successfully.</p> <p>ex) <WR></p>
	Response	<S>
WV	Format	<WV[IP addr]>
	Meaning	<p>Set Domain Name Server's IP address If you want to use Server information in Domain name, not IP address, then you should set Domain Name Server's IP address using this command. And the Domain Name Server's IP address which you entered should be valid and operate DNS query successfully.</p> <p>[IP Addr] : Server's IP address in a dotted decimal format</p> <p><WV8.8.8.8></p>
	Response	<S>
RV	Format	<RV>
	Meaning	<p>Get the current Domain Name Server IP address Its response format is like below. <S[IP Addr]></p> <p>[IP Addr] : Server's IP address in a dotted decimal format</p> <p>ex) <RV></p>
	Response	<S8.8.8.8>

WW	Format	<WW[Domain name]>
	Meaning	<p>Set Domain Name which you connect to. This information is meaningful as if you want use the data socket as Client mode or Mixed mode and set DNS enabled and set a proper DNS IP address. If one of them isn't set properly, despite you use this command, you can't get a good response.</p> <p>[Domain name] : Domain name in string type</p> <p>ex) <WWwww.google.com></p>
	Response	<S>
RW	Format	<RW>
	Meaning	<p>Get the current Domain Name set in WIZ127SR Its response format is like below <S[Domain Name]></p> <p>[Domain Name]</p>
	Response	<Swww.wiznet.co.kr>
WY	Format	<WY[ID]>
	Meaning	Set ID for PPPoE authentication
	Response	<S>
RY	Format	<RY>
	Meaning	<p>Get the current ID for PPPoE Its response format is like below <S[ID]></p> <p>[ID] :</p>
	Response	<Sadmin>
WZ	Format	<WZ[Passwd]>
	Meaning	Set Password for PPPoE authentication
	Response	<S>
RZ	Format	<RZ>
	Meaning	<p>Get the current password for PPPoE Its response format is like below. <S[Passwd]></p> <p>[Passwd] : Server's IP address in a dotted decimal format</p> <p>ex) <RZ></p>
	Response	<Sadmin>
OC	Format	<OC[ch]>
	Meaning	<p>Set a character delimiter¹ for making a ethernet data block in Hexadecimal format.</p> <p>[ch] : character information. Default value is 00. If this value is 00, it means Character</p>

¹ In normal, a serial device send data in chunk. Some device never expects those data chunk would be divided more than two pieces. But WIZ127SR handle data from serial interface byte by byte, in other word WIZ127SR check its serial buffer having data from serial interface and there are some data in that buffer, then it make a ethernet packet with those data and send that. But because the peer system expects all data chunk, that consider those data was broken and discard those.
 So, to avoid this fault, WIZ127SR provides three scheme to handle serial data chunk by chunk. Those are character delimiter, size delimiter and time delimiter.

		Delimiter disabled ex) <OC1B>
	Response	<S>
QC	Format	<QC>
	Meaning	Get the current character delimiter Its response format is like below. <S[ch]> [ch] : Server's IP address in a dotted decimal format ex) <QC>
	Response	<S41>
OS	Format	<OS[size]>
	Meaning	Set a size delimiter for making a ethernet data block in Decimal format [size] : size information. Its range is 0 ~ 255. Default value is 0. If this value is 0, it means Size Delimiter Disabled ex) <OS100>
	Response	<S>
QS	Format	<QS>
	Meaning	Get the current size delimiter value Its response format is like below. <S[size]> [size] : Server's IP address in a dotted decimal format ex) <QS>
	Response	<S40>
OT	Format	<OT[time]>
	Meaning	Set a time delimiter for making a ethernet data block in Decimal format [time] : time information. Its range is 0 ~65535. Unit is millisecond . Default value is 0. If this value is 0, it means Time Delimiter disabled ex) <OT100>
	Response	<S>
QT	Format	<QT>
	Meaning	Get the current time delimiter value Its response format is like below. <S[time]> [time] : Server's IP address in a dotted decimal format ex) <QT>
	Response	<S100>
OI	Format	<OI[time]>

	Meaning	<p>Set the inactivity time² for disconnecting the current established socket, as data communication is idle for some time which users already set</p> <p>[time] : time information. Its range is 0 ~65535. Unit is second. Default value is 0. If this value is 0, it means Inactivity Time disabled</p>
	Response	<S>
QI	Format	<QI>
	Meaning	<p>Get the current inactivity time value Its response format is like below. <S[time]></p> <p>[time] : Server's IP address in a dotted decimal format</p> <p>ex) <QI></p>
	Response	<S60>
RA	Format	<RA>
	Meaning	<p>Get the current MAC address of WIZ127SR Its response has a format like below. <S[MAC Addr]></p> <p>[MAC addr] : This is 6 ASCII String in a Hexadecimal format with delimiters, ':', following to every 2 characters.</p> <p>ex) <RA></p>
	Response	<S00:08:DC:00:11:22>
RF	Format	<RF>
	Meaning	<p>Get the current firmware version stored in WIZ127SR. Its response format is like below. <S[Ver]></p> <p>[Ver] : Server's IP address in a dotted decimal format</p> <p>ex) <RF></p>
	Response	<S3.1>

3.2. Data mode and Command mode

WIZ127SR has two operation mode - serial command mode and data mode through serial interface. These are concerned to the communication between host processor and WIZ127SR.

3.2.1. Data mode

Data mode is the default mode of WIZ127SR. After booting, WIZ127SR operates itself as 'Serial

² WIZ127SR itself doesn't disconnect a TCP connection after a connection established. Normally the peer system do that. But, there are many cases that users' system including WIZ127SR should close a established connection after a short data communication and any peer system of WIZ127SR doesn't have those capabilities. Inactivity time scheme is a useful function under this circumstance. If WIZ127SR doesn't receive any data from the serial interface during the time set as the Inactivity Time, then WIZ127SR closes the current established connection itself. But If any character is entered from the serial interface before the Inactivity Time timer is expired, the timer will be reinitialized.

to Ethernet; converter. It tries to connect or listens to get peer's connection request. During this mode, WIZ127SR holds the data from host processor via serial interface as just data. If the connection is already established, WIZ127SR transmits the data to peer system, and also receives data which are sent by the peer from Ethernet.

In other words, WIZ127SR transparently bypasses data from Ethernet to serial interface and vice versa without editing those data.

3.2.2. Serial Command mode

In serial command mode, WIZ127SR treats data from host processor as a command. If the command is valid, it sends a proper response. If not it responds with error message. In the serial command mode, there is no data communications between WIZ127SR and peer system.

If WIZ127SR enters into serial command mode, it will print out "<E" message through serial interface to inform host processor that it successfully entered into serial command mode.

But when it switches to data mode, it doesn't print out any message.

3.2.3. How to switch the mode

There two method to switch the mode from data to serial or vice versa. One is the software triggering and the other is the hardware triggering.

Software triggering

Host processor can make WIZ127SR enter into serial command mode by issuing software triggering string, which is already set by user through serial interface. User can set this string at the configuration tool, web config page or telnet.

In order to escape from serial command mode, host processor just issues <WR> command. Then, WIZ127SR reboots and operates as data mode.

Hardware triggering

Hardware Configuration enables the module to enter into configuration mode by port control.

If you supply the power or reset the module by asserting low 12th pin of JP1, you can configure the module using serial commands.

At the hardware configuration mode, network configuration or data communication is not allowed. Therefore, after finishing the configuration, be sure to assert high JP1.12 for normal operation.

A. Frame Format

Command Frame format

Descriptor	STX	Command code	Parameter	ETX
Command	'>'(0x3E)	R / W / X	Variable	'CR'(0x0D)
Length(bytes)	1	1	Variable	1

Table 9. Hardware Configuration Frame format

Reply Frame format

Descriptor	STX	Reply code	Parameter	ETX
Command	'<(0x3C)	S	Variable	'CR"LF'(0x0D0A)
Length(bytes)	1	1	Variable	2

Table 10. Hardware Configuration Reply Frame format

Command Code

Command	Comments
R	Read Parameter
W	Write Parameter
X	Exit Hardware Command mode
E	Command Error

Table 11. Hardware Configuration Command Code

Reply for Entrance Hardware Command Mode (Hex : 0x3B)

[Normal mode] ;
[Debug mode] WIZ127SR bootloader Ver. 1.0 Firmware Ver. 0.9 ;

Table 12. Hardware Configuration Entrance Message

The length of parameter can be different according to firmware version.

Value(byte)	Description																		
0008DCxxxxxx(6)	MAC address (xxxxxx is uniquely factory set)																		
01 (1)	Mode (00: TCP Client, 01 : TCP Mixed, 02 : TCP Server)																		
00000000 (4)	IP address																		
00000000 (4)	Subnet mask																		
00000000 (4)	Gateway address																		
0000 (2)	Local Port number (Module's Port Number)																		
00000000 (4)	Server IP address																		
0000 (2)	Server Port number																		
FE (1)	Serial speed (bps) Default is FE <table border="1" data-bbox="529 667 1490 741"> <tr> <td>BB:</td> <td>FF:</td> <td>FE:</td> <td>FD:</td> <td>FA:</td> <td>F4:</td> <td>E8:</td> <td>D0:</td> <td>A0:</td> </tr> <tr> <td>230400</td> <td>115200</td> <td>57600</td> <td>38400</td> <td>19200</td> <td>9600</td> <td>4800</td> <td>2400</td> <td>1200</td> </tr> </table>	BB:	FF:	FE:	FD:	FA:	F4:	E8:	D0:	A0:	230400	115200	57600	38400	19200	9600	4800	2400	1200
BB:	FF:	FE:	FD:	FA:	F4:	E8:	D0:	A0:											
230400	115200	57600	38400	19200	9600	4800	2400	1200											
08 (1)	Serial data size (08: 8 bit), (07: 7 bit)																		
00 (1)	Parity (00: No), (01: Odd), (02: Even)																		
01 (1)	Stop bit																		
00 (1)	Flow control (00: None), (01: XON/XOFF), (02: CTS/RTS)																		
00 (1)	Delimiter character																		
0000 (2)	Delimiter size																		
0000 (2)	Delimiter time																		
0000 (2)	Delimiter inactivity time																		
00 (1)	Debug code (00: ON), (01: OFF)																		
03 (1)	Software major version																		
01 (1)	Software minor version																		
00 (1)	DHCP option (00: DHCP OFF, 01:DHCP ON)																		
00 (1)	UDP mode (00: TCP; 01: UDP)																		
00 (1)	Connection Status (00:not connected, 01: connected)																		
00 (1)	DNS Flag (00:not use DNS, 01:use DNS)																		
00000000 (4)	DNS Server IP address																		
00.....00 (32)	Server Domain Name																		
00 (1)	Serial command method(00:disable, 01:enable)																		
2B2B2B (3)	Serial command mode character(Hex)																		
002020.....2020 (32)	PPPoE ID																		
002020.....2020 (32)	PPPoE Password																		
00 (1)	Password option for TCP Server (00:disable, 01:enable)																		
00000000000000000000 (8)	Password for TCP Server																		
FF	Last Byte (It means end of parameter)																		

Table 13. Hardware Configuration Parameter descriptions

B. Hardware Configuration Examples

Read Parameter

- STEP 1.** Supply the power into the module by asrting 12th pin of JP1.
- STEP 2.** Check if the message (‘:’) is displayed to notify the entering of Hardware Configuration. If module is set as ‘Debug mode’, the message is displayed after showing model name and version.

```
WIZ127SR bootloader
Ver. 1.0

Firmware Ver. 0.9
;
```

- STEP 3.** Input ‘>R’ and Carriage Return(0x0D).
- STEP 4.** Check response message.

```
WIZ127SR bootloader
Ver. 1.0

Firmware Ver. 0.9
;<S0008DC135E2401C0A80B03FFFFFF00C0A80B011388C0A80B011388FE0800010000000
0000000000003010000000000000000020202020202020202020202020202020202020202
0202020202020202020012B2B2B00202020202020202020202020202020202020202020
2020202020202000202020202020202020202020202020202020202020202020202020
2020000000000000000000FF
```

Changing IP Address

When changing the parameter value, the MAC address is not changed. As MAC address is the unique value for the module, user can’t change it. When changing the IP address, input the new value after first 6bytes.

- STEP 1.** Check HEX value of new IP address. In here, the new IP address is assumed as ‘192.168.11.10’. Therefore, the hex value ‘C0A80B0A’ is input.
- STEP 2.** Input ‘>W01C0A80B0AFFFFFFFF00 ... 00FF’.
- STEP 3.** Check ‘<S’ message is displayed. After displaying this message, CR(0x0D) & LF(0x0A) are displayed together.
- STEP 4.** After completing the change, check if changed value is appropriated saved by using READ command.

3.3. How to get the socket status

TBD

3.4. How to handle extra GPIO Pins

TBD

4. How to configure with WIZ127SR

4.1. Configuring with UDP broadcasting and WIZ127SR Configuration Tool

4.1.1. Network Configurations




Figure 5. Configuration Tool (Network Configuration)

1) Search

The Search function is used to search for all existing modules on the same LAN. By using UDP broadcast, it finds all modules on the same subnet, and the founded device will be listed in the “Serial to Ethernet” tree(Search Window) with its MAC address.

2) Setting

This function is to apply your configurations.

When you select the MAC address from the “Search Window”, the default value of the module will be displayed. Modify your configurations and click “Setting” button to apply your settings. The module will re-initialize and save the changed configurations.

You can change the configurations by following steps:

- ① Select the MAC address of the device which you would like to modify in the “Search

Window”

- ② Modify the settings according to your needs
- ③ Click the “Setting” button to apply your settings
- ④ The module will be initialized by a re-booting process
- ⑤ To verify your settings, please click ‘Search’ button and view your new settings

3) Firmware Upload

Firmware will be uploaded through your network. The Procedure of Firmware upload is explained details in “Chapter 3. Firmware Upload”

4) Factory Reset

All setting value is initialized to factory default, if you click the “Factory Reset” button.

5) Exit

Close the configuration tool program window.

6) Search Window

If you click the “Search” button, all the MAC addresses on the same subnet will be displayed.

7) Device network settings

Static: “Using the follow IP Address” is an option for setting WIZ127SR module’s IP with static IP address..

1. Select a MAC address which you want to set as static IP in the “Search Window”.
2. Check “Using the follow IP address”.
3. The “Device IP, Gateway, Subnet mask, DNS server” box will be enabled, and then input address in those fields.
4. Click the “Setting” button to apply your configurations.


DHCP: Select “Get IP address from DHCP server” option to use the DHCP mode.

1. Select the MAC address on the “Search Window”.
2. Check “Get IP address from DHCP server” and click the ‘Setting’ button.
3. A module will acquire network information from the DHCP server. (Should wait a moment to acquire network information from the DHCP server.)
4. When a module on the “Search Window” is selected, the IP address, Subnet mask and Gateway are displayed. If the module could not acquire the network information from the DHCP server, the IP address, the Gateway Address and the Subnet mask will be initialized as 0.0.0.0.

IP Address Information

- Device IP: WIZ127SR’s IP Address

- Gateway: WIZ127SR's Gateway Address
- Subnet mask: WIZ127SR's Subnet Mask
- DNS server: DNS Server's IP Address

 **If you are unclear about your Local IP, Subnet Mask, Gateway information, you have to get this information from your network administrator. If the IP address is not correct, IP collision or network problems may occur.**

8) F/W Version

It displays the firmware version.

9) Enable Serial Debug Mode

If this mode is enabled, you can monitor the status and socket messages of WIZ127SR through the serial terminal (listen OK, connect fail and etc.). In this mode, debug messages can cause abnormal operation of the serial device. Therefore, you should use this mode only for debugging.

10) Network Status

This field shows the Connection Status of UART0 and UART1 in WIZ127SR. The message "Connected" will be displayed when a peer successfully connects to WIZ127SR.

4.1.2. Serial Configuration




Figure 6. Configuration Tool (Serial Configuration)

You should set to UART configuration after checking UART tab whether it is UART0 or UART1. The numbers on the screenshot correspond to the descriptions listed below.

1) COM port setting

This menu is used for setting the serial port.

 **In order to apply your settings, click the “Setting” button**

2) Working mode

Client / server / mixed: This is to select the communication method based on TCP. TCP is the protocol to establish the connection before data communication, but UDP just processes the data communication without connection establishment. The Network mode of WIZ127SR can be divided into TCP Server, TCP Client and Mixed mode according to the connection establishing method. At the TCP server mode, WIZ127SR operates as server on the process of connection, and waits for the connection trial from the client. WIZ127SR operates as client at the TCP Client mode on the process of connection, and tries to connect to the server’s IP and Port. Mixed

modes supports both of Server and Client. The communication process of each mode is as below.

TCP server mode Communication

At the TCP Server mode, WIZ127SR waits for the connection requests.

TCP Server mode can be useful when the monitoring center tries to connect to the device (where WIZ127SR is installed) in order to check the status or provide the commands. In normal time WIZ127SR is on the waiting status, and if there is any connection request (SYN) from the monitoring center, the connection is established (ESTABLISH), and data communication is processed (Data Transaction). Finally connection is closed (FIN).

In order to operate this mode, “Device IP”, “Subnet mask”, “Gateway” and “Local port” should be configured first.

The Data transmission proceeds as follows,

1. The host connects to the WIZ127SR which is configured as TCP Server mode.
2. As the connection is established, data can be transmitted in both directions – from the host to the WIZ127SR, and from the WIZ127SR to the host

TCP client mode Communication

If WIZ127SR is set as TCP Client, it tries to establish connection to the server.

To operate this mode, “Device IP”, “Subnet mask”, “Gateway”, “Remote host”, and “Remote port” should be set. If “Remote host” has domain name, you should be confirmed the “DNS server” field.

In TCP Client mode, WIZ127SR can actively establish a TCP connection to a host computer when power is supplied.

The Data transmission proceeds as follows:

1. As power is supplied, WIZ127SR board operating as TCP client mode actively establishes a connection to the server.
2. If the connection is complete, data can be transmitted in both directions – from the host to the WIZ127SR and from WIZ127SR to the host

Mixed mode Communication

In this mode, WIZ127SR normally operates as TCP Server and waits for the connection request from the peer. However, if WIZ127SR receives data from the serial device before connection is established, it changes to the client mode and sends the data to the server IP. Therefore, at the mixed mode, the server mode is operated prior to the client mode.

As like TCP Server mode, the Mixed mode is useful for the case that the monitoring center tries to connect to the serial device (in which WIZ127SR is used) to check device status. In addition

to this, if any emergency occurs in the serial device, the module will change to Client mode to establish the connection to the server and deliver the emergency status of the device.

UDP mode Communication

UDP is not a connection oriented protocol. But the communication port should also be defined well. If the UDP mode is selected, the data from serial interface can be defined where to delivery via the “Remote host” and “Remote port”, and the WIZ127SR can also be defined where to receive Ethernet data from via the “Remote host” and “Local port” definition. If the data destination and source are the same, the two IP address will also be the same. Please note the destination and source are using the same port.

3) Communication

When your module is set as “Client mode”, “Mixed mode” or “UDP mode”, peer IP and port should be set in order for WIZ127SR to connect to the server(or peer).

- **Local port:** This field is to set the network port number in WIZ127SR.

 **You should set to different port number from each other UART port.**

- **Remote port:** This field is to set the network port number in remote device.
- **Remote host:** This field is to set the network address. (IP address or Domain name) of remote device.

If your application needs the DNS function, input the domain name of connecting node (E.g.: www.wiznet.co.kr) into “Remote host” field and the DNS Server IP address into “DNS server” field. Domain Name System (DNS) is a database system that associates the Domain name with the actual IP address. The purpose of the DNS system is to resolve the Domain name and represent it as an IP address. As a result, your device can connect to an actual IP address.

4) Timers

You can specify how the serial data can be packed to be sent to the Ethernet. There are 3 delimiters - time, size and character. If all of them are set as ‘0’, whenever the serial data is arrived, they are sent to the Ethernet immediately.

- **Nagle wait time:** This field specifies the waiting time. When there is no more input from the serial port, the module will wait for the specified time and then send out the serial data

to the network. For example, if 2000 ms is specified, the module will send out the packet at 2000 ms after the last input from the serial port. If there is no data in the serial buffer, the module will not send out any data packets. ('0': Function Disable)

- **Inactivity:** When there is no data transmission, the connection will be closed automatically after the time specified in the Inactivity time. If the default value '0' is set as the Inactivity time, the network connection is maintained even though there is no data transmission. In order to close the connection, you should use the 'Close' commands. This function is useful when you have two or more systems which are connected to the WZ127SR module. When one system is connected to the WIZ127SR, other systems cannot connect to the module simultaneously. If you defined a time in the Inactivity time, the other system can connect to the module after the inactivity time elapsed. Inactivity Time can also be used when the server system is unexpectedly shut down. In this case, there will not be any data communication. After the time defined in the Inactivity time elapsed, WIZ127SR will close the connection and enter into waiting state.

- **Reconnection:** The connection retry interval. (Client mode only)

5) Serial Configuration

This function is for module configuration not through network with configuration tool, web configuration and telnet but through serial communication. At the default status, the serial command mode is disabled. When you want to set via serial communication, check "enable". Please refer to "4. Serial Configuration" for more detail about serial configuration.

4.1.3. Option Configuration




Figure 7. Configuration Tool (Option Configuration)

You should set to UART configuration after checking UART tab whether it is UART0 or UART1. The numbers on the screenshot correspond to the descriptions listed below.

1) Device name

The device name is displayed in this area.

2) Serial number

The serial number of device is displayed in this area.

3) Password

The password that is used for web configuration and telnet is displayed in this area. The shown password is encrypted by MD5.

If you want to change the password, double-click the text-box and then type your password in ASCII codes.


4) NTP

NTP(Network Time Protocol) is a protocol for clock synchronization between computer systems over the networks. This function is reserved for customization. In case of standard version, this function just working for clock synchronization and display the time to configuration tool and web page.


- **Enable NTP:** This check-box is to set the enable/disable of NTP.
- **NTP Server IP:** This field is to set the NTP server IP address.
- **Device Time:** This field is to shown the current time of WIZ127SR.
- **Time Zone:** This field is to set the time zone of your country.

4.2. Configuring with Web browser

Open the web browser and input the IP address of the module. The first page will request the user password as shown in below figure.




If you input the password (the default value is WIZ127SR), the configuration page will be displayed. You can set the configuration parameters of network and serial.




4.3. Configuring with Telnet

You can configure the WIZ127SR by using Telnet Client(*) program. If you connect to the WIZ127SR, you can see the message of requesting user password.




Input the user password (Default P/W : WIZ127SR). You can see the message “Press ‘Q’ to enter the main console menu”.



```
c:\ 텔넷 192.168.11.100
Welcome to the WIZ127SR Telnet Console, please input your password> *****
Press 'Q' to enter the main console menu>
```

If you input the 'Q', the main menu for the WIZ127SR configuration is displayed.



```
c:\ 텔넷 192.168.11.100
Welcome to the WIZ127SR Telnet Console, please input your password> *****
Press 'Q' to enter the main console menu> Q
*****
* Configuration Menu *
*****
1 - Device settings
2 - Connection settings
3 - Other Options settings
$ - Save all changes without reboot
E - Exit
Enter your choice>
```

(*) You can use the Telnet client program which is provided by Windows OS. At the Windows XP, you can use the Telnet client program without additional setting. However at the Windows Vista or above version, you must enable the Telnet Client program first. For the detail, refer to the site <http://goo.gl/Plhyu>.

5. How to upload a new firmware

Run “WIZ127SR Configuration Tool” program, and click the “Search” button.

If the module is properly connected to the network, the MAC address will be displayed on the “Search Window” as shown in Figure 4.




Figure 8. Configuration Tool

Select a module shown in the “Search Window”, and click the “Firmware Upload” button.

👉 Before uploading the firmware through Ethernet, you should set the network information of WIZ127SR first, by Configuration Tool program as shown above in Figure 4. By using Ping test, you can check whether your network is configured correctly or not.

When the window as shown in Figure 5 is displayed, select file to upload and click the “Open” button.




Figure 9. Open dialog box for uploading

 Do not upload any other files except for WIZ127SR application firmware file.

The progress bar will be displayed as below.




Figure 10. Firmware uploading window

When uploading is completed, a message box with “Firmware download over” will be displayed as shown in Figure 7.





Figure 11. Complete Uploading

6. Quick Installation and Test

In this chapter, we will provide an example for you to learn how to install and test “Serial to Ethernet” data communication with the WIZ127SR.

<System Configuration>



- Hardware
 - PC having a RS-232 serial port and Ethernet port
 - WIZ127SR & WIZ127SR Base Board
 - Ethernet Cable (Direct or Crossover Cable)
- Software
 - WIZ127SR Configuration Tool
 - Hyper Terminal

<Testing Procedure>

1. Hardware Connection

- ① Connect the PC and WIZ127SR base board (in which the module is plugged) with serial cable
- ② Connect the PC and WIZ127SR base board by using Ethernet cable.
- ③ Supply the power to the test board.


2. Module Configuration

- ① In this manual, we are going to test the module with following configuration.


Category		Parameters
Network Configuration	IP Address	192.168.11.100
	Subnet	255.255.255.0
	Gateway	192.168.11.1

	Local port	5000
COM Port setting	Baud Rate	115,200
	Data bit	8
	Parity	None
	Stop bit	1
	Flow Control	None
Working mode		TCP server


- ② Check the network configuration of the PC and set the appropriate value. Both of module and PC should be in the same network. Therefore, the IP address of the PC should be 192.168.11.xxx with the subnet 255.255.255.0.




- ③ Execute the configuration tool program and search the module. Set the all parameters as indicated in




- ④ Check the COM port status of the PC and open the serial terminal.



- ⑤ Check the IP Address and port of WIZ127SR and connect to WIZ127SR.



- ⑥ If you input some characters at the windows of serial, you can see they are displayed in the TCP window.
- ⑦ Vice versa, type some characters in the windows of TCP Client, you can see the characters are displayed in the serial Windows.



7. Warranty

WIZnet Co., Ltd offers the following limited warranties applicable only to the original purchaser. This offer is non-transferable.

WIZnet warrants our products and its parts against defects in materials and workmanship under normal use for period of standard ONE(1) YEAR for the WIZ127SR board and labor warranty after the date of original retail purchase. During this period, WIZnet will repair or replace a defective products or part free of charge.

Warranty Conditions:

The warranty applies only to products distributed by WIZnet or our official distributors.

The warranty applies only to defects in material or workmanship as mentioned above. The warranty applies only to defects which occur during normal use and does not extend to damage to products or parts which results from alternation, repair, modification, faulty installation or service by anyone other than someone authorized by WIZnet Co., Ltd. ; damage to products or parts caused by accident, abuse, or misuse, poor maintenance, mishandling, misapplication, or used in violation of instructions furnished by us ; damage occurring in shipment or any damage caused by an act of God, such as lightening or line surge.

Procedure for Obtaining Warranty Service

Contact an authorized distributors or dealer of WIZnet Co., Ltd. for obtaining an RMA (Return Merchandise Authorization) request form within the applicable warranty period.

Send the products to the distributors or dealers together with the completed RMA request form.

All products returned for warranty must be carefully repackaged in the original packing materials.

Any service issue, please contact to sales@wiznet.co.kr