


## GTR Series

GTR Series



Part No.	A	B	C
GTR-7-3-4	7	3.5	4
GTR-9-5-8	9	5	8
GTR-10-5-5	10	5	5
GTR-11-5-9	11	5	9
GTR-12.5-8-12	12.6	8.1	12
GTR-13-7-6	13	7	6
GTR-13-7-12.7	13	7.1	12.7
GTR-14.5-10-8	14.5	10.2	8
GTR-16-8-13	16.5	8.2	13
GTR-16-8-16	16.5	8.2	16
GTR-16-10-7	16	10	7
GTR-16-10-10	16	10	10
GTR-18-10-6	18	10	6
GTR-20-10-5	20.5	10.2	5
GTR-20-10-10	20.5	10.2	10
GTR-21-13-6	21.2	12.7	6
GTR-22-14-10	22	14	10
GTR-23-11-14	23.6	11.4	14
GTR-25-15-8	25	15	8
GTR-25-15-12	25	15	12
GTR-28-16-13	28	16	13
GTR-28-16-20	28	16	20
GTR-31-19-8	31	19	8
GTR-40-27-15	40.6	27.4	15