

Portable Surface Resistance Meter



Portable Surface Resistance Meter
ST250010

The surface resistivity tester is designed to measure the resistivity and resistance to ground of mats, workbenches, floors and other components of an ESD controlled area.

Without the grounding connection, it measures the surface resistivity. With the grounding cord connected, it measures the resistance to the ground.