



FS-4400

Stick feeder PLCC-44

Manual stick feeder for PLCC-44

The manual stick feeder allows to feed components from a stick to all of DIMA's manual operated pick and place systems. Components go by gravity feed out of the stick. A sponge prevents the components from coming out of the stick. As soon as the wheel with the sponge is rotated the components are moved into the pick position.



Specifications:

Dimensions : **250x125x40 mm**
: **10x5x1.6 Inch**